
## User Guide and Assembly Instructions MIDZONE



### **Parts and Hardware**


**Attention:** Carefully check all parts according to the instructions before assembling. Please assemble carefully to avoid scratching surfaces, especially powder coated surfaces.


Item		Parts	Qty.
А		Back Assembly	1
В		Seat Assembly	1
С		Seat Mechanism	1
D		Armrest L/R	1
Е		Gas Lift	1
F	*	Base	1
G	<b>O</b>	Caster	5
Н		Lever	1
I		Bolt 4 x 8.5mm	1


Item	Parts	Qty.
J	Seat Mechanism Bolt	4
u	1/4 x 7/8mm Flat Pad	
К 🥥	19 x 8.3 x 2mm	6
L 👍	Adjusted Width Button	2
М	Inner Hexagon Screws 5/16 x 3/4mm	3
N O	Flat Pad 16 x 8.3 x 2mm	3
0	M2 Wrench	1
Р	M5 Wrench	1


# 1. Assemble the Base, Casters, & Gas Lift Insert five casters [G] into the base [F]. Push hard until you feel or hear the casters snap into place. With the base upright and the casters on the floor, insert the gas lift [E] into the base.

- 2. Assemble the Seat Mechanism & Seat Attach lever [H] to the seat mechanism [C] using bolt [I] and secure with wrench [O]. Attach the assembled seat mechanism to the seat using flat pads [K] and seat mechanism bolt [J] using wrench [P].
- 3. Assemble the Seat Assembly & Back Keep the seat assembly [C+H+B] on a table first, then insert the back assembly [A] between connected seat assembly and seat plane. Turn the back assembly into the center of three holes. Attach using a wrench [P]. Fully tighten the inner hexagon socket screws [M] and flat pad [N].











#### 4. Assemble the Armrest & Seat

Attach the armrests [D] to the seat assembly [C+H+B] using the adjusted width button [L] to fasten the armrests over the seat assembly.





### **Product Dimensions**

