



Installation / Drawer Rails



To remove drawer, push the left lever up, the right lever down, and slide drawer forward.





To install drawer, make sure to pull the middle rail forward, as shown in close up.

Combo lateral 2b/2f

Before installing lateral, remove the drawers according to « Instruction / Drawer Rails » ,and remove the top.

If the underside of the worksurface panel has **NO HOLES(?)** as shown in figure A, Please use the 4 provided **WOOD SCREWS** to attach the lateral. Secure the lateral by the 4 smaller **Screw** holes in the lateral.



If the underside of the worksurface panel has **BOLT HOLES** as shown in figure B, Please use the 4 provided **BOLTS & WASHERS** to attach the lateral to the left or right side of the panel. Secure the lateral by the 4 Larger **BOLT** holes in the lateral. **AND** please use the 2 provided **WOOD SCREWS** to attach the lateral. Secure the lateral by the 2 smaller **Screw** holes in the lateral.

